


Why temperature?


Salmonids - CWA (TMDL) / ESA


Questions to Ask -


- Source Assessment ("Why")
- Management Actions ("What if")
- Evaluate Management ("What")


These issues are addressed through data collection and analysis



































































































































Summary


- Utilize Local Knowledge
- Evaluate at both Local and Watershed Scales
- Utilize Holistic Approach
 - Flow/Shade/Channel
 - Spatial Patterns





Impacts of Dams on Flowing Rivers


- · Stratification warm surface, cold bottom
- Inundation of local cold water refugia
- Flow augmentation/depletion
 - Effects vary, including
 - cooling effect from Dworshak cold water augmentation
 - warming of diel peak temperature due to White River/Lake Tapps bypass
- Temporal shift in seasonal temperatures
 - Subject of TMDL and FERC studies for a number of rivers, including Columbia, Snake, Willamette, and Deschutes











Monitoring Considerations

- · Assessing diversion effects
 - Need flow/temperature data above dam and at base of bypass reach at a minimum
- · Assessing temporal shift using measurements
 - Comparing apples to apples mixed temps
 - set upstream station in free-flowing reach
 - set downstream station in tailrace to obtain a mixed temp for comparison to upstream flowing reach
 - · need full year of continuous data to assess shift

Commonly Used Models to Evaluate Dam Effects

- CE-QUAL-W2 (most commonly used in Northwest)
 - Developed by Portland State and Army COE
 - 2D (laterally averaged temperature at a given depth)
 - Includes effects of density and outlet structures on release temps
- RBM10 and MASS1
 - Developed by EPA Region 10 and Batelle, respectively
 - 1D (cross sectional average temperature)
 - Used for analysis of Columbia and Snake mainstems
- EFDC
 - Developed by EPA contractors (Tetra Tech)
 - 3D (estimates lateral and vertical variation)
 - Used for small scale questions (e.g., confluences, near-dam effects)